Wichtige Information!



Aufgrund der Bestimmungen der Firma Apple, sind folgende softwarespezifischen Vorgaben bei der Inbetriebnahme von **VoiceMaker** sowie **M 100** einzuhalten:

Um ein iPod/iPhone-Gerät mit einem der o.g. **TLS-Geräten** in Betrieb zu nehmen,

- 1. selektieren Sie zuerst den Menüpunkt iPod mit der FUNC-Taste.
- 2. Setzen Sie dann das iPod/iPhone-Gerät in den dafür vorgesehenen Adapter.

Hinweis: Die erfolgreiche Erkennung des iPod/iPhone-Gerätes wird im Display des CD-Players mit dem Hinweis Success bestätigt.



Achten Sie unbedingt auf die Reihenfolge der Einstellungen, da sich die Geräte ansonsten nicht erkennen! Bevor diese Erkennung nicht sichtbar wurde, arbeiten VoiceMaker wurde sowie M 100 micht bestimmungsgemäß!

Das angeschlossene iPod/iPhone-Gerät kann entsprechend der Bedienungsanleitung direkt oder über **VoiceMaker** sowie **M 100** auch mit der Fernbedienung gesteuert werden.

Sollen nach der Auswahl einer anderen Quelle, z. B. CD, erneut Beiträge von dem iPod/iPhone-Gerät über **VoiceMaker** oder **M 100** Wiedergegeben werden, ist die gleiche Vorgehensweise wie oben beschrieben einzuhalten!



Das iPod/iPhone-Gerät benötigt vor jeder Inbetriebnahme ZWINGEND eine Initialisierung!

Ihr TLS Customer-Service

Important information!



According to the regulation of Apple, the following software-specific requirements had to be ensure to operate **VoiceMaker** and **M 100**

To activate an iPod/iPhone device with one the **TLS devices** mentioned above,

- 1. select at first the menu item iPod with the key FUNC.
- 2. Then connect the iPod/iPhone device to the docking station on the top of the product.

Note: Once the recognition of the iPod/iPhone device is successful, the information is displayed in the **CD player**.



To ensure a proper set up of the iPod/iPhone device, it is important to follow these instructions! Otherweise the recognition **Success** will be not displayed at the products **VoiceMaker** and **M 100** is and **M 100**.

The connected iPod/iPhone device is now ready to operate direct over the **VoiceMaker** and **M 100** also by using the remote control.

By selecting another source in the **FUNC** menu, e. g. CD, the initialisation of the iPod/iPhone device will be lost. To reinitialise the device follow the above mentioned description.



The iPod/iPhone device needs to be set up by reconnecting the device to docking station!

Your TLS customer service