

Beach Wagon LITE®

SEAT

SKU 75.1DGY

Seat
Sitz
Zitje

EN
DE
NL




























IN/125

SEAT for Beach Wagon LITE. Check warnings before every use of the wagon.

WARNING: This seat is meant for children from 18 month of age.

Always use locking device or special Beach Wagon LITE Brake to prevent wagon from rolling away.



-  **WARNING! A CHILD'S SAFETY IS YOUR RESPONSIBILITY.**
-  **WARNING! Never leave a child unattended. It may be dangerous to leave your child unattended.**
-  **WARNING! This wagon is not intended for children under 3 years.**
-  **WARNING! Maximum load of the Beach Wagon LITE® is 80 KG. Never overload. Never load more children than the wagon is suitable for.**
-  **WARNING! Never let a person stand in the wagon.**
-  **WARNING! This wagon is not suitable for running or skating.**
-  **WARNING! Always read the instructions BEFORE use. Keep these instructions for future reference.**
-  **WARNING! Assembly of the Beach Wagon LITE® by adults only!**
-  **WARNING! This wagon shall be used with caution, since skill is required to avoid falls or collisions causing injury to the user or third parties!**
-  **WARNING! Do not attach the wagon to any other vehicle, car, bicycle, motor or animal. Do not use on highway. Only use for walking. Maximum speed 10 KM per hour.**
-  **WARNING! Avoid serious injury from falling or sliding out of the wagon.**
-  **WARNING! Always use this wagon with care to avoid injury, falling and collision.**
-  **WARNING! Always divide the load evenly over the wagon. Overloading on one side might cause tilting of the wagon.**
-  **WARNING! When the wagon is used in the sun, there is a hazard of sun burn. Use sun protection for children.**
-  **WARNING! Keep flames and heat away from the wagon.**
-  **WARNING! This wagon requires regular maintenance by the user. See the maintenance instruction in this manual.**
-  **WARNING! Ensure that all accessories are engaged / constructed according the advised instructions in the manual of these accessories before use.**
-  **WARNING! To avoid injury ensure that your child is kept away from the wagon when unfolding and folding this wagon.**
-  **WARNING! Keep plastic covers and bags away from children to avoid suffocation and hazard.**
-  **WARNING! Children should be kept on a distance of moving parts while making adjustments.**

2020-09-24