

Sport-Thieme® 'Alpha' Stopwatch


Product no. 11 252 0504

Instruction manual

Sports timer with alarm, stopwatch, 1/100 second, lap and split timing

Functions:


1. Display of hour, minute, second and day of the week
2. Display of month and date
3. Stopwatch accurate to 1/100 second, with lap and split timing
4. 4-years calendar
5. Acoustic signal, acoustic alarm, hourly time signal and snooze button
6. 30 second correction for synchronisation
7. Optional 12-hour or 24-hour display
8. Maximum timing range: 23 hours, 59 minutes, 59 seconds



Display change:

Standard display: hour, minute, second & day of the week

1. Press and hold #1 to display 'month/date'
2. Press and hold #2 to display 'alarm time'
3. Press #3 to display mode control for stopwatch-functions
4. Press #3 again to access 'set alarm' function
5. Press #3 again to access 'set time' function
6. Press #3 again to read the time



Settings:

Time:

1. Press #3 three times to access 'set time' function, 'seconds' flash. Press #1 to set the seconds.
2. Press #2, 'minutes' flash. Press #1 to set the minutes.
3. Press #2, 'hours' flash. Press #1 to set the hours.
4. Press #2, 'date' flashes. Press #1 to set the date.
5. Press #2, 'month' flashes. Press #1 to set the month.
6. Press #2, 'day of the week' flashes. Press #1 to set the day of the week.
7. Finally, press #3 once to return to the 'time' display.

12/24 hours selection:

When setting 'hours', the '12/24 hour display' selection can be made by rotating.

AM/PM in the 12-hour format or 'H' in the 24-hour format.

Alarm time:

1. Press #3 twice, the alarm time 'hours' flashes. Press #1 to set the hour.
2. Press #2 once, the alarm time 'minutes' flashes. Press #1 to set the minutes.
3. Finally press #3 once to return to the 'time' display.

Stopwatch:

1. Press #3 to access the 'stopwatch' mode. Press #1 – you can now use the start-stop function for timing.
2. During timing, you can press #2 to activate the 'lap time' mode. This means one element of the timing is displayed whilst timing continues in the background.
3. Press #2 to return to the current timing.

Alarm function:

1. Press and hold #2 and additionally press #1 to turn the alarm function on and off.
2. When the alarm is turned on, a bell is displayed in the top right corner.
3. An alarm will sound when the alarm is turned on and the time reaches the alarm time.
4. The alarm ends automatically after 60 seconds. However, it can also be stopped by pressing #1. In both cases the alarm will sound at the same time on the next day.

Hourly time signal:

1. Press and hold #2 and additionally press #3 to turn the hourly time signal on and off.
2. When the hourly time signal is turned on, the flags (abbreviated days of the week) are displayed.

Snooze button:

1. When the 'beep, beep' alarm sounds, turn the 'snooze' function on by pressing #1. The alarm will now sound again in five minutes time, unless it is turned off by pressing #2.

Battery:

Replace battery with same type.